



E → D → F → H → G → I → B → A → C

1. Carefully remove the fixture out of the carton, and check that all parts are included referring to the above illustration. Make sure not to misplace any parts that are needed for the installation.
2. Take the mounting plate (D) over the wall where you want to install this fixture and adjust it to the proper position, then make the marks on the wall for the 2 key holes ' position.
3. Drill the holes at the position where marked at the above step, and install the plastic anchors (E) onto them well.
4. Attach the mounting plate (D) over the wall using 2 set screws (F) thread into the plastic anchors (E) and let the set screws (F) set at the long slot of the key hole well, then secure the set screw (F) tightly.
5. Position the canopy (H) over the mounting plate (D), aligning the 2 holes on the canopy (H) with the 2 holes from the mounting plate (D). Insert the 2 canopy screws (G) and tighten to secure the Canopy (H) in place , then making sure the 2 screws on the mounting plate (D) extend through the 2 holes on the canopy (H), secure the canopy (H) by tightening 2 ball nuts (I) to the screws.
6. Carefully place the shade (B) to the socket assembly (A), securing with socket ring (C).
7. Install proper bulb (not provided) to the sockets referring to the marking and/or labels on the fixture for maximum wattage.
8. Fixture is ready for lamping and installation.