



ASSEMBLY INSTRUCTIONS

1. Carefully unpack and identify all parts referring to illustration for parts identification.
2. Turn the power to the installation point OFF.
3. While threading wire through, assemble the rods (4) together using the nipples (3). Attach the bottom end of the rods (4) into the coupling (6) until hand tight.
4. Secure the loop (5) onto the top of the rods (4).
5. Insert the G9 bulb (8) into the socket (7). Install the crystal ball (9) on the socket (7) and secure with the finial (10).
6. Use quick link to connect the loop (5) to the loop on the canopy (1) and twist the locking mechanism to secure.
7. Refer to the additional installation instructions included with the product for wiring and installation.
8. Restore power to the installation point and retain this sheet for future reference.