

- 1. Carefully unpack and identify all parts referring to illustration for parts identification.
- 2. Turn the power to the installation point OFF.
- 3. Unfold arms of fixture to desired positions.
- 4. While threading wire through, assemble the rods (4) together using the nipples (3). Attach the end of the rods (4) into the coupling(6) until hand tight.
- 5. Secure the loop (5) onto the other end of the rods (4).
- 6. Use quick link to connect the loop (5) to the loop on the canopy (1) and twist the locking mechanism to secure.
- 7. Install the G9 bulb (8) into each socket (7) and install the glass shade (9) onto the socket (7).
- 8. Refer to the additional installation instructions included with the product for wiring and installation.
- 9. Restore power to the installation point and retain this sheet for future reference.