


ASSEMBLY INSTRUCTIONS

ITEM NO.: M70102

Replace carabina system to be swivel



1. Remove the loops from the canopy (L) and center tube(K).
2. Install the threaded swivel (L1) onto the top of center tube (K).
3. Place the canopy (L2) over the threaded swivel (L1) to the fixture body (A), then place the washer (L3) onto the protruding nipple at the top center of fixture body (A), securing with hex nut (L4).